

Brother 1060 – Re-inking Instructions

*Sometimes Brother 1060 get a little funky about re-inking.
If normal re-inking doesn't work,
you may want to try these suggestions from the manufacturer.*

Re-ink normally by removing the top and filling the holes with Brother Ink. (*For illustrated instructions, please see the [Brother Re-inking link](#).*)

The 1060 sometimes take a little longer for the ink to get to the ends initially because they're so narrow compared to the other sizes. It might just need to sit a little longer.

You can also try adding a little more ink to see if that will help force the ink to the middle.

If nothing else works, put some ink on the surface of the stamp in the middle and leave it upside down for a few minutes to let it soak in, then wipe the excess off with a paper towel. Stamping it few times should get the excess ink off of the surface. Not sure how much ink you can really get into a stamp that way, but it seems to work.