

Installation of new replacement ink cartridges

New replacement ink cartridges for 4911, 4912, 4913







Hold side buttons while pushing down to lock in position. (as shown)



Push front button to push out old pad. (as shown)



Insert pad into slot with inked side facing down. Tabs will snap off when the pad is fully inserted.



Collect and discard tabs.

